DIAMOND WATER INC.

P.O. Box 200, Hwy. 76-JJ, Greenville, WI 54942 USA 414/757-5440 Fax 414/757-5819

PROCEDURE TO PROGRAM DAY OVERRIDE 460 NOVRAM AND 460i

UNPLUG 460 TIMER.

PUT JUMPER ON "A"

PLUG TIMER IN

REMOVE JUMPER FROM "A" AND PLACE ON "B"

PRESS "TIME SET BAR"

YOU CAN PROGRAM FROM ZERO TO 15 DAYS

ZERO = NO DAY OVERRIDE.

460 AND 4601 FACTORY RESET PROCEDURE

UNPLUG TIMER.

LOCATE SPARE JUMPER ON BACK SIDE OF JUMPER DOOR FOR THE 460 OR ON SPARE PEGS ON THE 460i.

PLACE JUMPERS ON "A" AND "B" PEGS.

PLUG TIMER BACK IN.

DISPLAY SHOULD READ "88".

PUT SPARE JUMPER BACK.

RESET ALL SETTINGS ON TIMER.